

Configuring RIP with CLI

This section provides information to configure Routing Information Protocol (RIP) using the command line interface.

Topics in this section include:

- [RIP & RIPng Configuration Overview on page 268](#)
- [Basic RIP Configuration on page 269](#)
- [Common Configuration Tasks on page 270](#)
 - [Configuring Interfaces on page 271](#)
 - [Configuring a Route Policy on page 272](#)
 - [Configuring RIP Parameters on page 274](#)
 - [Configuring Global-Level Parameters on page 276](#)
 - [Configuring Group-Level Parameters on page 277](#)
 - [Configuring Neighbor-Level Parameters on page 278](#)
- [RIP Configuration Management Tasks on page 279](#)
 - [Modifying RIP Parameters on page 279](#)
 - [Deleting a Group on page 280](#)
 - [Deleting a Neighbor on page 280](#)

RIP & RIPng Configuration Overview

Preconfiguration Requirements

Configure the following entities before beginning the RIP configuration:

- (Optional) Policy statements should be defined in the `config>router>policy-options` context.
-

RIP Hierarchy

RIP is configured in the `config>router>rip` context. RIP is not enabled by default. Three hierarchical levels are included in RIP configurations:

- Global
- Group
- Neighbor

Commands and parameters configured on the global level are inherited by the group and neighbor levels although parameters configured on the group and neighbor levels take precedence over global configurations.

Basic RIP Configuration

This section provides information to configure RIP and examples of common configuration tasks. For a router to accept RIP updates, in the `config>router>rip` context, you must define at least one group and one neighbor. A router will ignore updates received from routers on interfaces not configured for RIP. Configuring other RIP commands and parameters are optional.

By default, the local router imports all routes from this neighbor and does not advertise routes. The router receives both RIPv1 and RIPv2 update messages with 25 to 255 route entries per message.

The RIP configuration commands have three primary configuration levels: `rip` for global configurations, `group group-name` for RIP group configurations, and `neighbor ip-int-name` for RIP neighbor configurations. Within the different levels, the configuration commands are identical. For the repeated commands, the command that is most specific to the neighboring router is in effect; that is, neighbor settings have precedence over group settings which have precedence over RIP global settings.

The minimal RIP parameters that need to be configured in the `config>router>rip` context are:

- Group
- Neighbor

The following example displays a basic RIP configuration.

```
ALA-A>config>router>rip# info
-----
      group "RIP-ALA-A"
          neighbor "to-ALA-4"
          exit
      exit
-----
ALA-A>config>router>rip#
```

Common Configuration Tasks

This section provides a brief overview of the tasks that must be performed to configure RIP and provides the CLI commands.

Configure RIP hierarchically using the global level (applies to all peers), the group level (applies to all peers in peer-group), or the neighbor level (only applies to the specified interface). By default, group members inherit the group's configuration parameters although a parameter can be modified on a per-member basis without affecting the group-level parameters.

Many of the hierarchical RIP commands can be used on different levels. The most specific value is used. That is, a RIP group-specific command takes precedence over a global RIP command. A neighbor-specific statement takes precedence over a global RIP or group-specific command.

All RIP instances must be explicitly created on each device. Once created, RIP is administratively enabled.

To configure RIP, perform the following tasks:

1. Configure interfaces
2. Configure policy statements (optional)
3. Enable RIP
4. Configure group parameters
5. Configure neighbor parameters

Configuring Interfaces

The following command sequences create a logical IP interface. The logical interface can associate attributes like an IP address, port, Link Aggregation Group (LAG), or the system. For more information about configuring interfaces, refer to the *IP Router Configuration Overview* chapter.

To configure a network interface:

CLI Syntax: config> router
 interface *ip-int-name*
 address *ip-addr{/mask-length|mask}* [broadcast {all-
 ones|host-ones}]
 port *port-id*

The following example displays router interface configuration command usage:

Example: config>router> interface "to-ALA-4"
 config>router>if\$ address 10.10.12.1/24
 config>router>if# port 1/1/1
 config>router>if# exit

The following example displays the IP configuration output showing the interface information.

```
ALA-3>config>router# info
-----
echo "IP Configuration "
-----
  interface "system"
    address 10.10.10.103/32
  exit
  interface "to-ALA-4"
    address 10.10.12.1/24
    port 1/1/1
  exit
-----
ALA-3>config>router#
```

Configuring a Route Policy

The import route policy command allows you to filter routes being imported by the local router from its neighbors. If no match is found, the local router does not import any routes.

The export route policy command allows you to determine which routes are exported from the route table to RIP. By default, RIP does not export routes it has learned to its neighbors. If no export policy is specified, non-RIP routes will not be exported from the routing table manager to RIP.

If multiple policy names are specified, the policies are evaluated in the order they are specified. The first policy that matches is applied. If multiple export commands are issued, the last command entered will override the previous command. A maximum of five policy names can be specified.

This section only provides brief instructions to configure route policies. For more details, refer to the *Route Policy Overview* chapter.

To enter the mode to create or edit route policies, you must enter the `begin` keyword at the `config>router>policy-options` prompt. Other editing commands include:

- The `commit` command saves and enables changes made to route policies during a session.
- The `abort` command discards changes that have been made to route policies during a session.

Use the following CLI syntax to configure a policy to use for the RIP global, group, and neighbor import and export commands.

CLI Syntax:

```
config>router>policy-options
    begin
    commit
    abort
    policy-statement name
        description text
        default-action {accept|reject}
        entry entry-id
            description text
            action {accept|reject}
            from
            to
```

Use the following CLI syntax to enter the edit mode:

CLI Syntax: config>router> policy-options
begin

The following example displays some commands to configure a policy statement. Policy option commands are configured in the config>router context. Use the commit command to save the changes.

Example: config>router>policy-options# begin
policy-options# policy-statement"RIP-policy"
policy-options>policy-statement\$ description "this is a
test RIP policy"
policy-options>policy-statement>default# entry 1
policy-options>policy-statement>entry\$ action accept
policy-options>policy-statement>entry# exit
policy-options>policy-statement# default-action reject
policy-options>policy-statement# exit
policy-options# commit

```
ALA-A>config>router>policy-options# info
-----
policy-statement "RIP-policy"
description "this is a test RIP policy"
entry 1
action accept
exit
exit
default-action reject
exit
-----
ALA-A>config>router>policy-options>policy-statement#
```

Configuring RIP Parameters

Use the CLI syntax displayed below for:

- [Configuring Global-Level Parameters on page 276](#)
- [Configuring Group-Level Parameters on page 277](#)
- [Configuring Neighbor-Level Parameters on page 278](#)

CLI Syntax:

```
config>router
    rip
        authentication-key [authentication-key|hash-key
            [hash|hash2]
        authentication-type {none|password|message-digest|mes-
            sage-digest-20}
        check-zero {enable|disable}
        description string
        export policy-name [policy-name ...up to 5 max]
        import policy-name [policy-name ...up to 5 max]
        message-size number
        metric-in metric
        metric-out metric
        preference number
        receive {both|none|version-1|version-2}
        send {broadcast|multicast|none|version-1|both}
        no shutdown
        split-horizon {enable|disable}
        timers update timeout flush

    group group-name
        authentication-key [authentication-key|hash-key
            [hash|hash2]
        authentication-type {none|password|message-digest|mes-
            sage-digest-20}
        check-zero {enable|disable}
        description string
        export policy-name [policy-name ...up to 5 max]
        import policy-name [policy-name ...up to 5 max]
        message-size number
        metric-in metric
        metric-out metric
        preference number
        receive {both|none|version-1|version-2}
        send {broadcast|multicast|none|version-1}
        no shutdown
        split-horizon {enable|disable}
        timers update timeout flush
```

```
neighbor ip-int-name
    authentication-key [authentication-key|hash-key
        [hash|hash2]]
    authentication-type {none|password|message-digest|
        message-digest-20}
    check-zero {enable|disable}
    description string
    export policy-name [policy-name ... up to 5 max]
    import policy-name [policy-name ... up to 5 max]
    message-size number
    metric-in metric
    metric-out metric
    preference number
    receive {both|none|version-1|version-2}
    send {broadcast|multicast|none|version-1}
    split-horizon {enable|disable}
    timers update timeout flush
    no shutdown
```

Configuring Global-Level Parameters

Once the RIP protocol instance is created, the `no shutdown` command is not required since RIP is administratively enabled upon creation. Minimally, to enable RIP on a router, at least one group and one neighbor must be configured. There are no default groups or neighbors. Each group and neighbor must be explicitly configured.

NOTE: Careful planning is essential to implement commands that can affect the behavior of global, group, and neighbor-levels. Because the RIP commands are hierarchical, analyze the values that can disable features on a particular level. Use the following CLI syntax to configure global-level RIP parameters:

```
CLI Syntax: config>router
               rip
                   authentication-key [authentication-key|hash-key
                   [hash|hash2]
                   authentication-type {password|message-digest}
                   check-zero {enable|disable}
                   export policy-name [policy-name ...up to 5 max]
                   import policy-name [policy-name ...up to 5 max]
                   message-size number
                   metric-in metric
                   metric-out metric
                   preference number
                   receive {both|none|version-1|version-2}
                   send {broadcast|multicast|none|version-1|both}
                   no shutdown
                   split-horizon {enable|disable}
                   timers update timeout flush
```

The following example displays global RIP configuration command usage:

```
Example: config>router# rip
           config>router>rip# authentication-type password
           config>router>rip# authentication-key test123
           config>router>rip# receive both
           config>router>rip# split-horizon enable
           config>router>rip# timers 300 600 600
           config>router>rip>group# exit
```

The following example displays the RIP group configuration:

```
ALA-A>config>router>rip# info
-----
           authentication-type simple
           authentication-key "ac18651vz1d" hash
           timers 300 600 600
-----
ALA-A>config>router>rip#
```

Configuring Group-Level Parameters

A group is a collection of related RIP peers. The group name should be a descriptive name for the group. Follow your group, name, and ID naming conventions for consistency and to help when troubleshooting faults.

All parameters configured for a group are applied to the group and are inherited by each peer (neighbor), but a group parameter can be overridden on a specific neighbor-level basis. Use the following CLI syntax to configure a group:

```
CLI Syntax: config>router# rip
                group group-name
                    authentication-key[authentication-key|hash-key
                    [hash|hash2]
                    authentication-type {password|message-digest}
                    check-zero {enable|disable}
                    description string
                    export policy-name [policy-name ...]
                    import policy-name [policy-name ...]
                    message-size number
                    metric-in metric
                    metric-out metric
                    preference number
                    receive {both|none|version-1|version-2}
                        send {broadcast|multicast|none|version-1|both}
                        no shutdown
                        split-horizon {enable|disable}
                        timers update timeout flush
```

The following example displays group configuration command usage:

```
Example: config>router# rip
            config>router>rip# group headquarters
            config>router>rip>group$ description "Mt. View"
            config>router>rip>group# no shutdown
```

The following example displays the RIP group configuration:

```
ALA-A>config>router>rip# info
-----
authentication-type simple
authentication-key "ac18651vz1d" hash
timers 300 600 600
group "headquarters"
    description "Mt. View"
exit
-----
ALA-A>config>router>rip#
```

Configuring Neighbor-Level Parameters

After you create a group name and assign options, add neighbor interfaces within the same group. All parameters configured for the peer group level are applied to each neighbor, but a group parameter can be overridden on a specific neighbor basis.

Use the following CLI syntax to add a neighbor to a group and define options that override the same group-level command value:

CLI Syntax: config>router# rip
group *group-name*
neighbor *ip-int-name*
authentication-key [*authentication-key|hash-key*
[*hash|hash2*]
authentication-type {password|message-digest}
check-zero {enable|disable}
description *string*
export *policy-name* [*policy-name ...*]
import *policy-name* [*policy-name ...*]
message-size *number*
metric-in *metric*
metric-out *metric*
preference *number*
receive {both|none|version-1|version-2}
send {broadcast|multicast|none|version-1}
split-horizon {enable|disable}
timers update timeout *flush*
no shutdown

The following example displays neighbor configuration command usage:

Example: config>router# rip
config>router>rip# group headquarters1
config>router>rip>group# neighbor ferguson-274
config>router>rip>group>neighbor\$ preference 255
config>router>rip>group>neighbor# send both
config>router>rip>group>neighbor# split-horizon enable
config>router>rip>group>neighbor# message-size 255

The following example displays the neighbor configured in group “headquarters”.

```
ALA-A>config>router>rip>group>neighbor# info
-----
      message-size 255
      preference 255
      split-horizon enable
      no timers
-----
ALA-A>config>router>rip>group>neighbor#
```

RIP Configuration Management Tasks

Examples are provided for the following RIP configuration management tasks:

- [Modifying RIP Parameters on page 279](#)
 - [Deleting a Group on page 280](#)
 - [Deleting a Neighbor on page 280](#)
-

Modifying RIP Parameters

Modify, add or remove RIP parameters in the CLI. The changes are applied immediately. For the complete list of CLI commands, refer to [Configuring RIP Parameters on page 274](#).

CLI Syntax: config>router# rip
group *group-name*
...
neighbor *ip-int-name*
...

Example: config>router>rip# group "headquarters"
config>router>rip>group# neighbor "ferguson-274"
config>router>rip>group>neighbor# import RIPpolicy
config>router>rip>group>neighbor# message-size 150

The following example displays the updated parameters:

```
ALA-A>config>router>rip# info
-----
authentication-type simple
authentication-key "ac18651vz1d" hash
timers 300 600 600
group "headquarters"
    description "Mt. View"
    neighbor "ferguson-274"
        import "RIPpolicy"
        message-size 150
        preference 255
        split-horizon enable
        no timers
    exit
exit
-----
ALA-A>config>router>rip#
```

Deleting a Group

A group must be shut down first in order to delete it.

Use the following CLI syntax to shut down and then delete a group:

CLI Syntax: config>router# rip
[no] group *group-name*
shutdown

Example: config>router# rip
config>router>rip# group "RIP-ALA-3"
config>router>rip>group# shutdown
config>router>rip>group# exit
config>router>rip# no group "RIP-ALA-3"

If you try to delete the group without shutting it down first, the following message appears:

```
INFO: RIP #1204 group should be administratively down - virtual router
index 1,group RIP-ALA-4
```

Deleting a Neighbor

The neighbor must be shut down before it can be deleted.

Use the following CLI syntax to delete a neighbor:

CLI Syntax: config>router# rip
[no] group *group-name*
[no] neighbor *ip-int-name*
shutdown

Example: config>router# rip
config>router>rip# group "RIP-ALA-4"
config>router>rip>group# neighbor "to-ALA-3"
config>router>rip>group>neighbor# shutdown
config>router>rip>group>neighbor# exit
config>router>rip>group# no neighbor "to-ALA-3"

If you try to delete the neighbor before it is shut down, the following message appears:

```
INFO: RIP #1101 neighbor should be administratively down - virtual router
index
```